

Wedgegard® Chain Coupling Manual Reset

Torque Table / ft-lbs



DATASHEET Version 6/2023

Model	S350		S500		S700		S950		S1000
WEDGEPIN	W37		W50		W50		W100		W100
Brass = B / STEEL = S	B	S	B	S	B	S	B	S	S
TORQUE CODES	* Wedgepins x 3		* Wedgepins x 3		* Wedgepins x 3		* Wedgepins x 3		* Wedgepins x 4
O	33	45	38	52	93	128	-	-	-
OW	46	63	53	73	141	202	-	-	-
GD	62	85	72	99	-	-	-	-	-
W	86	118	100	136	203	278	612	841	2559
WY	123	170	143	196	275	378	859	1180	3806
Y	163	224	189	260	359	520	1088	1497	5119
YB	216	297	251	344	525	722	1482	2036	6432
BN	223	-	260	-	-	-	-	-	-
B	254	349	295	405	722	991	1770	2434	7243
BG	297	407	344	472	901	1238	2102	2876	8563
G	366	503	425	583	1102	1512	2655	3614	10237
RG	443	609	514	706	1391	1910	3098	4204	-
R	498	685	578	794	1438	1975	3540	4868	11786
RK	-	-	-	-	-	-	-	-	-
K	-	-	-	-	1499	2058	4130	5642	12480

* For a guide on Wedgepin identification, please visit our Website.

Release Torque figure are for a full complement of Wedgepins fitted and are adjusted by reducing the number of Wedgepins fitted, or by changing the torque code.

Release Torques can be subject to the drive speed together with the rate and frequency of loading in the drive train.

**All figures quoted above are calculated using gradually applied loads.



Tel: +44 (0)1453 750814
 Fax: +44 (0)1453 765320
 www.howdon.co.uk
 sales@howdon.co.uk

