

# Wedgegard® Type SAE Spacer Manual Reset

DATASHEET Version 6/2023

## Torque Table / Nm



SAE SPACER	SAE 14		SAE 31		SAE35		SAE 41		SAE 51		SAE60		SAE 70		SAE 80	
WEDGEPIN SIZE	W37		W37		W37		W37		W50		W50		W75		W75	
BRASS = B / STEEL = S	B	S	B	S	B	S	B	S	B	S	B	S	B	S	B	S
TORQUE CODES	Wedgpins x 3		Wedgpins x 3		Wedgpins x 3		Wedgpins x 3		Wedgpins x 3		Wedgpins x 4		Wedgpins x 4		Wedgpins x 4	
O	134	185	134	185	162	224	162	224	383	526	588	806	-	-	-	-
OW	186	255	186	255	226	310	226	310	580	832	890	1277	-	-	-	-
GD	251	345	251	345	305	419	305	419	-	-	-	-	-	-	-	-
W	348	478	348	478	422	580	422	580	834	1145	1280	1757	3287	4512	3287	4512
WY	502	690	502	690	609	836	609	836	1132	1555	1737	2386	4612	6336	4612	6336
Y	663	910	663	910	804	1103	804	1103	1480	2142	2271	3286	5848	8026	5848	8026
YB	878	1207	878	1207	1065	1464	1065	1464	2164	2972	3320	4560	7964	10936	7964	10936
BN	910	-	910	-	1103	-	1103	-	-	-	-	-	-	-	-	-
B	1035	1421	1035	1421	1255	1724	1255	1724	2972	4082	4560	6263	9539	13098	9539	13098
BG	1207	1657	1207	1657	1464	2009	1464	2009	3712	5098	5695	7822	11267	15471	11267	15471
G	1490	2046	1490	2046	1808	2481	1808	2481	4538	6226	6962	9553	14135	19415	14135	19415
RG	1802	2476	1802	2476	2185	3003	2185	3003	5729	7867	8790	12070	16590	22656	16590	22656
R	2030	2785	2030	2785	2460	3377	2460	3377	5925	8135	9090	12480	19045	26155	19045	26155
RK	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
K	-	-	-	-	-	-	-	-	6175	8478	9472	13000	22090	30336	22090	30336

\* For a guide on Wedgpin identification, please visit our Website.

Release Torque figure are for a full complement of Wedgpins fitted and are adjusted by reducing the number of Wedgpins fitted, or by changing the torque code.

Release Torques can be subject to the drive speed together with the rate and frequency of loading in the drive train.

\*\*All figures quoted above are calculated using gradually applied loads.



Tel: +44 (0)1453 750814  
 Fax: +44 (0)1453 765320  
 www.howdon.co.uk  
 sales@howdon.co.uk

